

JOHN DEERE*



REPLACEMENT PARTS FOR JOHN DEERE* DIESEL ENGINES

PART NO.*	DESCRIPTION*
DP-AR103073	INJECTOR
DP-AR103466	NOZZLE
DP-AR31247	INJECTOR
DP-AR34421R	NOZZLE ASSEMBLY
DP-AR36053	INJECTOR
DP-AR36672	NOZZLE ASSEMBLY
DP-AR43205	NOZZLE ASSEMBLY
DP-AR43831	NOZZLE ASSEMBLY
DP-AR44509	NOZZLE ASSEMBLY
DP-AR49227	NOZZLE ASSEMBLY
DP-AR49308	NOZZLE ASSEMBLY
DP-AR49876	NOZZLE ASSEMBLY
DP-AR49877	NOZZLE ASSEMBLY
DP-AR50781	NOZZLE ASSEMBLY
DP-AR50782	NOZZLE ASSEMBLY
DP-AR50783	NOZZLE ASSEMBLY
DP-AR50784	NOZZLE ASSEMBLY
DP-AR52014	NOZZLE ASSEMBLY
DP-AR52015	NOZZLE ASSEMBLY
DP-AR52374	INJECTOR
DP-AR53355	INJECTOR
DP-AR54566	INJECTOR
DP-AR56289	NOZZLE ASSEMBLY
DP-AR56290	NOZZLE ASSEMBLY
DP-AR65867	NOZZLE ASSEMBLY
DP-AR67765	NOZZLE ASSEMBLY
DP-AR68364	NOZZLE ASSEMBLY
DP-AR69046	INJECTOR
DP-AR69269	NOZZLE ASSEMBLY
DP-AR69290	NOZZLE ASSEMBLY
DP-AR70186	INJECTOR
DP-AR70188	INJECTOR
DP-AR70189	INJECTOR
DP-AR73637	NOZZLE
DP-AR73638	NOZZLE
DP-AR73672	NOZZLE ASSEMBLY
DP-AR73673	NOZZLE ASSEMBLY
DP-AR74153	NOZZLE ASSEMBLY
DP-AR74667	NOZZLE
DP-AR74668	NOZZLE
DP-AR74669	NOZZLE
DP-AR77008	NOZZLE ASSEMBLY
DP-AR77009	NOZZLE ASSEMBLY
DP-AR77220	INJECTOR
DP-AR78030	NOZZLE ASSEMBLY
DP-AR78031	NOZZLE ASSEMBLY
DP-AR78308	INJECTOR
DP-AR78489	INJECTOR
DP-AR79685	NOZZLE
DP-AR85616	NOZZLE ASSEMBLY
DP-AR86888	NOZZLE
DP-AR87468	INJECTOR
DP-AR87495	INJECTOR
DP-AR88236	NOZZLE ASSEMBLY
DP-AR88237	NOZZLE ASSEMBLY
DP-AR88238	NOZZLE ASSEMBLY
DP-AR88239	NOZZLE ASSEMBLY
DP-AR88240	NOZZLE ASSEMBLY

PART NO.*	DESCRIPTION*
DP-AR88241	NOZZLE ASSEMBLY
DP-AR89287	NOZZLE
DP-AR89563	NOZZLE ASSEMBLY
DP-AR89564	NOZZLE ASSEMBLY
DP-AR89817	NOZZLE ASSEMBLY
DP-AR90023	NOZZLE ASSEMBLY
DP-AR90024	NOZZLE ASSEMBLY
DP-AR97404	INJECTOR
DP-AT17067	INJECTOR
DP-AT17241	NOZZLE
DP-AT18064T	NOZZLE ASSEMBLY
DP-AT21760T	NOZZLE ASSEMBLY
DP-AT25502	NOZZLE ASSEMBLY
DP-AT27612	NOZZLE ASSEMBLY
DP-AT30296	NOZZLE ASSEMBLY
DP-AT30299	NOZZLE ASSEMBLY
DP-AT44508	NOZZLE ASSEMBLY
DP-R34574	NOZZLE
DP-R48697	NOZZLE
DP-R49511	NOZZLE
DP-R55083	NOZZLE
DP-R62610	NOZZLE
DP-RE10937	INJECTOR
DP-RE10938	NOZZLE
DP-RE10947	NOZZLE
DP-RE30970	INJECTOR
DP-RE30972	INJECTOR
DP-RE30973	INJECTOR
DP-RE30975	INJECTOR
DP-RE31533	INJECTOR
DP-RE31534	NOZZLE ASSEMBLY
DP-RE31614	NOZZLE ASSEMBLY
DP-RE31757	NOZZLE ASSEMBLY
DP-RE31900	NOZZLE ASSEMBLY
DP-RE31901	NOZZLE ASSEMBLY
DP-RE31903	NOZZLE ASSEMBLY
DP-RE36935	NOZZLE ASSEMBLY
DP-RE36936	NOZZLE ASSEMBLY
DP-RE36939	NOZZLE ASSEMBLY
DP-RE37503	NOZZLE ASSEMBLY
DP-RE38087	NOZZLE ASSEMBLY
DP-RE42306	NOZZLE
DP-RE46364	INJECTOR
DP-RE47803	INJECTOR
DP-RE47969	NOZZLE
DP-RE48360	NOZZLE
DP-RE48658	INJECTOR
DP-RE48786	NOZZLE ASSEMBLY
DP-RE57153	NOZZLE
DP-RE61593	INJECTOR
DP-RE64390	NOZZLE
DP-RE64391	INJECTOR
DP-RE64392	NOZZLE
DP-RE64533	NOZZLE
DP-RE66687	NOZZLE

*All manufacturers names, numbers, symbols and descriptions are used for reference purpose only and do not imply that any part listed is the product of these manufacturers.